




BELT SIZING



CONVERT V-BELT PART NUMBER TO OUTSIDE CIRCUMFERENCE

A Section = Add 2" to belt number
 (Example A88 = 90" Outside Circumference)

B Section = Add 3" to belt number; larger than 210 add 1"
 (Example B88 = 91" Outside Circumference, B212 = 213" Outside Circumference)

C Section = Add 4" to belt number; larger than 210 add 2"
 (Example C88 = 92" Outside Circumference; C212 = 214" Outside Circumference)

D Section = Add 5" to belt number; larger than 210 add 3"
 (Example D105=110" Outside Circumference, D212=215" Outside Circumference)

E Section = Add 6" to belt number; larger than 210 add 4"
 (Example E144=150" Outside Circumference, E220=224 Outside Circumference)



sales@cppdist.com | cppdist.com
 TF 1.800.871.4160 | CAN 780.438.0483 | USA 832.557.5663